



Permissions For Reprints Contact: 1-800-640-8285

## How To Adjust Timing of Flush Valve Water Flow

There is nothing worse than half a flush when a full flush is what you need. Like the poker four-flush, it doesn't quite make for a winner.

### Utensils

Smooth or flat-jaw adjustable wrench  
Medium flat blade screwdriver

### Approximate Time: 5 To 10 Minutes

1. Do not cut off water supply.
2. Remove nut on top of valve assembly (Fig. 84A).
3. Turn screw that is beneath nut in counterclockwise direction, one-fourth turn at a time (Fig. 84B).
4. Flush intermittently until proper amount of water is passed through.
5. If this doesn't do the trick, go on to the next recipe.




Figure 84.  
Adjusting the Water Supply